

## CA Series Fluid Chillers

Installation and Maintenance Instructions.



## Content

|   | page |
|---|------|
| Specifications, Performance data and Operation Parameters | 3    |
| Layout and Location Details                               | 7    |
| Controls  | 10   |
| Installation  | 13   |
| Commissioning   | 16   |
| Pre-start Check List                                      | 16   |
| Regular and Seasonal Maintenance                          | 18   |
| Troubleshooting   | 20   |
| Commissioning Data  | 22   |
| Service Notes   | 23   |

| MODEL                                       | CA10                  | CA15  | CA20                  | CA26  | CA33  | CA40   | CA52  | CA66  |
|---|-----------------------|-------|-----------------------|-------|-------|--------|-------|-------|
| <b>REFRIGERATION SYSTEM</b>                 |                       |       |                       |       |       |        |       |       |
| Cooling Capacity at nominal conditions, kW* | 11                    | 15    | 20                    | 25    | 32    | 39     | 51    | 64    |
| Number of systems                           | 1                     |       |                       |       |       |        | 2     |       |
| Refrigerant charge/system, kg               | 4                     | 4     | 5                     | 7.5   | 7.5   | 8.5    | 7.5   | 7.5   |
| Capacity control steps total/unit           | 1                     |       | 2                     |       |       |        |       |       |
| <b>COMPRESSORS</b>                          |                       |       |                       |       |       |        |       |       |
| type  | recip                 | recip | recip                 | recip | recip | scroll | recip | recip |
| number of compressors                       | 1                     |       |                       |       |       |        | 2     |       |
| Power requirements                          | 400 V, 3 phase, 50 Hz |       |                       |       |       |        |       |       |
| Nominal Power input/compressor, kW*         | 3.6                   | 6.0   | 6.7                   | 8.9   | 12.1  | 11.2   | 8.9   | 12.1  |
| Nominal current/compressor, A*              | 6.9                   | 11.1  | 12.3                  | 14.4  | 19.6  | 20.9   | 14.4  | 19.6  |
| Maximum power input/compressor, kW          | 5.7                   | 8.9   | 10.4                  | 13.6  | 17.5  | 18.6   | 13.6  | 17.5  |
| Maximum operating current/compressor, A     | 12.5                  | 18.5  | 22.0                  | 27.0  | 36.0  | 35.0   | 27.0  | 36.0  |
| Oil charge/compressor, L                    | 1.8                   | 1.8   | 3.9                   | 3.9   | 3.9   | 6.2    | 3.9   | 3.9   |
| <b>EVAPORATOR</b>                           |                       |       |                       |       |       |        |       |       |
| type  | shell & tube          |       |                       |       |       |        |       |       |
| water connections (vessel only), mm         | 25                    | 25    | 25                    | 50    | 50    | 50     | 50    | 50    |
| Nominal water flow rate, l/s                | 0.5                   | 0.7   | 1                     | 1.2   | 1.6   | 2      | 2.5   | 3.2   |
| <b>CONDENSER</b>                            |                       |       |                       |       |       |        |       |       |
| number of fans                              | 1                     |       | 1                     |       |       | 2      |       |       |
| Power requirements                          | 240 V, 1 ph., 50 Hz   |       | 400 V, 3 phase, 50 Hz |       |       |        |       |       |
| Nominal Total Current, A                    | 3                     |       | 5                     |       |       | 10     |       |       |
| Nominal Total Power, kW                     | 0.55                  |       | 2.6                   |       |       | 5.2    |       |       |
| Total air flow, l/s                         | 2870                  |       | 4983                  |       |       | 6940   | 7998  |       |
| fan sound pressure level, dB(A) at 3 m      | 48                    |       | 61                    |       |       | 67     | 65    |       |
| Unit maximum operating current, A           | 15.5                  | 21.5  | 27.0                  | 32.0  | 41.0  | 45.0   | 64.0  | 82.0  |

\*All ratings at nominal operating conditions: 12 C water return temperature, 7 C leaving water temperature, 35 C ambient

| MODEL                                       | CA80                  | CA96   | CA115 | CA132 | CA150 | CA175 | CA200 |
|---|-----------------------|--------|-------|-------|-------|-------|-------|
| <b>REFRIGERATION SYSTEM</b>                 |                       |        |       |       |       |       |       |
| Cooling Capacity at nominal conditions, kW* | 79                    | 96     | 114   | 131   | 158   | 191   | 216   |
| Number of systems                           | 2                     |        |       |       |       |       |       |
| Refrigerant charge/system, kg               | 9                     | 12     | 12    | 15    | 16    | 20    | 20    |
| Capacity control steps total/unit           | 2                     |        | 4     |       |       |       |       |
| <b>COMPRESSORS</b>                          |                       |        |       |       |       |       |       |
| type  | scroll                | scroll | recip | recip | recip | recip | recip |
| number of compressors                       | 2                     |        |       |       |       |       |       |
| Power requirements                          | 400 V, 3 phase, 50 Hz |        |       |       |       |       |       |
| Nominal Power input/compressor, kW*         | 11.2                  | 16.4   | 17.5  | 22.4  | 23.7  | 30.9  | 37.3  |
| Nominal current/compressor, A*              | 20.9                  | 28.3   | 30.6  | 41.0  | 41.3  | 56.1  | 75.3  |
| Maximum power input/compressor, kW          | 13.6                  | 28.4   | 25.0  | 30.0  | 35.0  | 42.0  | 51.0  |
| Maximum operating current/compressor, A     | 35.0                  | 47.0   | 44.0  | 53.2  | 62.1  | 73.9  | 96.2  |
| Oil charge/compressor, L                    | 6.2                   | 8      | 4.5   | 4.75  | 4.5   | 4.75  | 4.75  |
| <b>EVAPORATOR</b>                           |                       |        |       |       |       |       |       |
| type  | shell & tube          |        |       |       |       |       |       |
| water connections (vessel only), mm         | 50                    | 80     | 80    | 80    | 80    | 100   | 100   |
| Nominal water flow rate, l/s                | 3.8                   | 4.7    | 5.5   | 6.5   | 7.2   | 8.4   | 9.5   |
| <b>CONDENSER</b>                            |                       |        |       |       |       |       |       |
| number of fans                              | 4                     |        |       |       | 8     |       |       |
| Power requirements                          | 400 V, 3 phase, 50 Hz |        |       |       |       |       |       |
| Nominal Total Current, A                    | 20                    |        |       |       | 40    |       |       |
| Nominal Total Power, kW                     | 10.4                  |        |       |       | 20.8  |       |       |
| Total air flow, l/s                         | 13880                 |        |       | 15997 |       | 27760 |       |
| fan sound pressure level, dB(A) at 3 m      | 70                    |        |       | 68    |       | 73    |       |
| Unit maximum operating current, A           | 90.0                  | 114.0  | 108.0 | 126.4 | 164.2 | 187.8 | 232.4 |

\*All ratings at nominal operating conditions: 12 C water return temperature, 7 C leaving water temperature, 35 C ambient

NOTE:

- Ratings are based on units with no restriction to recirculation of condenser air
- Ratings are based on units with no ducting to condenser fans. Please refer FCA for application with ducting.
- For stable chiller operation flow rate must be constant +/-10% otherwise controls will not function correctly. Water of fluid pump must be selected to overcome the resistance of the evaporator(s) plus all pipe work, fittings and any other additional head losses in the pumping circuit.
- Standard refrigerant: R407C. Other refrigerants: please refer FCA.

Fluid Chillers Australia Pty Ltd reserve the right to change or modify specifications as required by continuing design and production variations without notice. All specifications should be used as a guide to the application of the equipment.

Full details on specific equipment must be obtained at the time of supply.

This Application Manual does not constitute an offer for sale of any product.

**Capacity correction factors.**

Leaving water temperature.

|                |      |      |      |      |      |      |      |      |      |      |       |
|----------------|------|------|------|------|------|------|------|------|------|------|-------|
| Temperature, C | 0.00 | 1.00 | 2.00 | 3.00 | 4.00 | 5.00 | 6.00 | 7.00 | 8.00 | 9.00 | 10.00 |
| factor         | 0.77 | 0.80 | 0.83 | 0.87 | 0.90 | 0.93 | 0.97 | 1.00 | 1.03 | 1.06 | 1.09  |

Operation outside indicated temperature range: please refer FCA.

For applications below +4 C glycol or ethanol antifreeze with appropriate corrosion inhibitor required.

Ambient Air Temperature.

|                        |      |      |    |      |      |
|------------------------|------|------|----|------|------|
| Ambient Temperature, C | 25   | 30   | 35 | 40   | 45   |
| Factor                 | 1.15 | 1.07 | 1  | 0.93 | 0.86 |

Operation above +40 C ambient temperature: please refer FCA.

Water flow rate.

Flow Rates other than 5 C temperature difference across the chiller vessel(s).

|                     |      |      |      |      |      |      |
|---------------------|------|------|------|------|------|------|
| Temp. difference, C | 3.00 | 3.50 | 4.00 | 4.50 | 5.00 | 5.50 |
| factor              | 0.94 | 0.96 | 0.97 | 0.99 | 1.00 | 1.02 |

Operation outside indicated temperature differences: please refer FCA.

**Nominal water flow rates and pressure drops.**

| MODEL              | CA10 | CA15 | CA20 | CA26 | CA33 | CA40 | CA52 | CA66 |
|--------------------|------|------|------|------|------|------|------|------|
| Flow rate, l/s     | 0.5  | 0.7  | 1.0  | 1.2  | 1.6  | 2.0  | 2.5  | 3.2  |
| Pressure drop, kPa | 15   | 15   | 15   | 15   | 15   | 28   | 30   | 30   |


| MODEL              | CA80 | CA96 | CA115 | CA132 | CA150 | CA175 | CA200 |
|--------------------|------|------|-------|-------|-------|-------|-------|
| Flow rate, l/s     | 3.8  | 4.7  | 5.5   | 6.5   | 7.2   | 8.4   | 9.5   |
| Pressure drop, kPa | 56   | 125  | 146   | 37    | 37    | 41    | 41    |

For applications below +4 C glycol or ethanol antifreeze with appropriate corrosion inhibitor required as per the following table.

| Minimum Percentage of Antifreeze Required |      |      |      |      |      |      |      |
|---|------|------|------|------|------|------|------|
| Temperature leaving Chiller, C            | 3    | 0    | -1   | -3   | -5   | -7   | -9   |
| Ethanol % vol                             | 15   | 17.5 | 20   | 22.5 | 25   | 27.5 | 30   |
| dP correction factor                      | 1.00 | 1.01 | 1.03 | 1.05 | 1.07 | 1.09 | 1.10 |
| Propylene Glycol % vol                    | 13   | 16   | 18   | 23   | 27   | 31   | 35   |
| dP correction factor                      | 1.05 | 1.12 | 1.15 | 1.20 | 1.25 | 1.30 | 1.40 |
| Ethylene Glycol % vol                     | 7    | 9    | 12   | 16   | 21   | 25   | 29   |
| dP correction factor                      | 1.01 | 1.03 | 1.05 | 1.10 | 1.15 | 1.20 | 1.25 |

Do not exceed 40% vol antifreeze as performance may be adversely affected.


## 2. Layout and Location Details.



2 fan unit on extended frame with optional 400 L buffer tank indicated.

### Note:

- Minimum 1 m clearance required all sides for air intake and unit service
- Sufficient clearance required above the unit to prevent recirculation of vertical discharge condenser air.



4 fan unit on extended frame with optional 400 L buffer tank indicated.

Note:


- Minimum 1 m clearance required all sides for air intake and unit service
- Sufficient clearance required above the unit to prevent recirculation of vertical discharge condenser air.

| MODEL            | CA10 | CA15 | CA20 | CA26 | CA33 | CA40 | CA52 | CA66 |
|------------------|------|------|------|------|------|------|------|------|
| Physical data    |      |      |      |      |      |      |      |      |
| Length L1, mm*   | 1440 | 1440 | 2340 | 2340 | 2340 | 2340 | 2340 | 2340 |
| Length L2, mm**  | 2200 | 2200 | 3100 | 3100 | 3100 | 3100 | 3100 | 3100 |
| Width, mm        | 920  | 920  | 920  | 920  | 920  | 1136 | 1136 | 1136 |
| Height, mm       | 1258 | 1258 | 1378 | 1378 | 1378 | 1378 | 1378 | 1378 |
| Nett weight, kg* | 280  | 280  | 368  | 375  | 380  | 580  | 590  | 600  |

\* unit on a standard frame and without accessories.

\*\* unit on extended frame with optional buffer tank





8 fan unit on extended frame with optional 400 L buffer tank indicated.

Note:

- Minimum 1 m clearance required all sides for air intake and unit service
- Sufficient clearance required above the unit to prevent recirculation of vertical discharge condenser air.

| MODEL            | CA80 | CA90 | CA100 | CA115 | CA132 | CA150 | CA175 | CA200 |
|------------------|------|------|-------|-------|-------|-------|-------|-------|
| Physical data    |      |      |       |       |       |       |       |       |
| Length L1, mm*   | 2340 | 2340 | 2340  | 2340  | 2340  | 2340  | 2340  | 2340  |
| Length L2, mm**  | 3100 | 3100 | 3100  | 3100  | 3100  | 3100  | 3100  | 3100  |
| Width, mm        | 1684 | 1684 | 1684  | 1684  | 2370  | 3266  | 3266  | 3266  |
| Height, mm       | 1378 | 1378 | 1378  | 1378  | 1418  | 1458  | 1458  | 1458  |
| Nett weight, kg* | 840  | 880  | 890   | 1100  | 1200  | 1680  | 1750  | 1880  |

\* unit on a standard frame and without accessories.

\*\* unit on extended frame with optional buffer tank

### 3. Control system operation.

The chiller units are fitted with a set of operating and safety controls to ensure reliable and efficient operation of the chiller. Their function and operation is described below.

#### Control Thermostat–Cooling (ETC)

As all the chillers have capacity control, a multi-stage electronic thermostat sensing inlet and outlet water temperatures, controlling the stages of capacity as required. The CA range of chillers have 2, 3 or 4 stages of capacity depending on model.


The control sensor (b1) is located in a pocket in the inlet water connection to the chiller vessel.

The set point is factory set to suit the application as ordered, and will provide leaving chilled water at approximately 5°K cooler than the set point at the nominal water flow rate. The set point is adjustable from +18°C to –7°C and must be set on site to suit the application. Factory set-point limits are put in place for the designed application and may have to be reprogrammed on-site for different applications.

As the thermostat is sensing return water temperature it must be set approximately 4°K to 5°K above the desired leaving water temperature (depending on the water flow rate).

**If the desired leaving water temperature is below +4°C an anti-freeze such as ethanol, Alcool LF, ethylene or propylene glycol must be added to the water**

#### Programming Instructions



- |                                      |                  |
|--------------------------------------|------------------|
| 1. Temperature Display               | 5. Key: SET      |
| 2. Active Outputs (flash on standby) | 6. Key: PRG/Mute |
| 3. Reverse Mode (heating)            | 7. Key: Up       |
| 4. Direct Mode (cooling)             | 8. Key: Down     |

#### Set Point(s)

1. Press & hold "SET" for 5 seconds – on releasing button, Set Point 1 (ST1) will be displayed.
2. Press arrow "Up" or "Down" to set the desired value.
3. Press "SET" to confirm value

The system has only 1 set point, the controller will display the measured variable (ie. water temperature). If the controller has been programmed for more than one stage the differential will remain constant regardless of set point.

Differential (P1) must be set to match the flow rate. This will normally be 1 to 2°C per capacity stage.

#### **Low Water Temperature Thermostat (LWT)**

This function is performed by temperature probe b2 on the IR33 controller. It senses leaving water temperature, and shuts the controller outputs down when this temperature drops below normal safe operating temperature. This control is provided to prevent freezing of the chiller vessel due to low flow or insufficient anti-freeze. The sensing bulb is located in a pocket in the leaving water connection of the chiller vessel.

The set point is factory set at 2°C with a 2°C differential, however for low temperature applications the set point is set 2°C below the minimum desired leaving water temperature.

This thermostat is not included in the safety lockout circuit and will reset automatically.

#### **Low Refrigerant Temperature Thermostat (LRT)**

This thermostat is provided to detect a lower than normal refrigerant temperature resulting from a fault in the refrigerant or water system, which could lead to freezing of the chiller vessel. The sensing element is attached to the low pressure liquid line at the inlet to the evaporator. The set point is factory set at -2°C with a 2°C differential, however for low temperature application the set point needs to be set to approximately 8°C below the desired leaving chilled water temperature. This thermostat is incorporated in the safety lock-out circuit and hence, when activated, it will shut the faulty refrigeration circuit down.

#### **High/Low Refrigerant Pressure Switch (HP/LP)**

These switches are provided to protect the compressor in the event of a malfunction in some part of the system. The low pressure switch is factory set to cut out 430kPa and the high pressure switch is factory set to cut out at 2600 kPa.

For low temperature applications the low pressure switch should be set to cut out at 100 kPa. The high pressure switch needs no adjustment.

Both switches are included in the safety lockout circuit and when activated will shut the faulty refrigeration circuit down.

#### **Motor Temperature Thermostats (MT)**

Both the compressor and the condenser fan motor(s) are fitted with either an auto-reset Thermal klixon or a contactor mounted thermal overload block which protects the motor(s) by shutting them down should they become overheated due to a malfunction in some part of the system. The klixon embedded in the motor windings is inaccessible. The fan motor thermostats are included in the safety lockout circuit and when activated shut the chiller down.

The compressor internal thermostat shuts down the compressor directly and will automatically reset after some time.

**Repeated operation of this device indicates a fault requiring service.**

#### **Delay Start Timer**

The Electronic Control thermostat (IR33) has inbuilt timers to delay the start of second stage compressors and also to provide anti short cycle timing on compressor start ups. The factory settings are 60 second delay on start and 6 minute Start to Start anti short cycle delay.



### Flow Switch

A flow switch (or similar device) must be provide and wired into the chiller electrical circuit, as shown in the wiring diagram.

### Phase Sequence Relay

A phase sequence relay is fitted to the CA40, and CA80 units to prevent the scroll compressors from running backwards if wired incorrectly. A yellow indicator will light up if wired correctly. If the indicator does not light up, phase direction will require correction at the main terminal block.

### Remote Control Switch

Provision for a remote control switch is provided as shown on the wiring diagram. If not used, a link must be put in place.


## 4. Installation.

### Receiving Unit

Upon receipt, the unit should be carefully examined for any damages that may have occurred in transit, and such damage should be noted on the carrier's delivery documents. It is the consignee's responsibility to make any subsequent claims upon the carrier or the respective insurance company.

### Lifting Unit

When slinging the unit, care must be taken to prevent rope damage to the paintwork or components. The unit can be lifted by means of slings under the bottom rails (refer the picture below). Since the weight is not equally distributed in the placement of the slings in order to obtain the proper balance.



### Locating the Unit

The CA series units are fully weatherproof and should be located outdoors preferably, or if indoors must be in a well ventilated area. When installed in either indoor or outdoor locations, care should be taken to prevent the re-circulation of air to the condenser.

This range of packaged air cooled chillers are designed to be installed outdoors with no obstructions to the vertical condenser air discharge.

**CAUTION: The unit must not be installed indoors or in an area which may restrict condenser air flow, without extreme care being taken to ensure a plentiful, unrestricted and continues supply of ambient temperature air. Ducting of standard condenser fans will void warranty.**

The unit must be installed on a firm level foundation, of adequate strength to support its full operating weight. Some form of vibration isolation such as rubber waffle pads should be installed between the unit and the supporting structure.

1. The unit must not be located where it will be subjected to heavy downpour of roof drainage and must be above ground level in areas that are prone to stormwater flooding.
2. All electrical connections to the unit must be made via flexible connections to prevent transmission of vibration.
3. Service and air-flow clearances must be allowed as indicated on the unit dimension sheet. It should be noted that major service may require removal of the top panels.
4. Duct work must not be attached to condenser fan outlets, due to engineering and design considerations.
5. In addition to the service clearances noted on the dimension sheet, it is essential that provisions be made for adequate and safe service access.

### **Water System Installation**

**CAUTION: Where these chillers are to be used in a process where the product is intended for human consumption the product should not pass directly through the chiller unit. A secondary heat exchanger should be installed in accordance with appropriate local regulations and or statutory requirements.**

1. To maintain effective system control it is recommended that an insulated Thermal Inertia Tank is included in the chilled water circuit. This tank can also serve as the make-up water tank, fill point and expansion tank.
2. The chilled water piping should be arranged so that the circulating pump is installed on the entering waterside of the chiller (discharges into chiller). The piping should be sized for a velocity not exceeding 2 m/s to minimise the pressure drop in the system.
3. The piping should be located and supported so that excessive weight is not borne by the chiller connections.

#### **PLEASE NOTE:**

**The chilled water piping must be installed with either barrel unions or flanged fittings to facilitate removal of the chiller vessels for service.**

4. All the piping (including PVC pipe) and fittings should be insulated, with a water-resistant material such as Aeroflex or Armaflex. To prevent the formation of condensation and the resultant loss of chiller capacity.
5. The piping should include sufficient shut-off valves to permit draining of the water from the chiller without draining the complete system. It should also include thermometers at the inlet and outlet connections and air vents at the high points.
6. All systems should include a method of measurement to establish flow rate, acceptable methods include:
  - a. Pressure tapping either side of the chiller in order that the pressure drop across unit can be determined. (The pressure drop graph is shown on page 2.)
  - b. Flow meter, orifice plate or calibrated balancing valve.
  - c. Pump pressure gauge, in conjunction with temperature gauges either side of chiller.
7. A cleanable type water strainer with a Mesh of approximately 20 mesh is recommended at the inlet to the chiller. This is absolutely essential on installations where the chilled water piping is made up of steel pipe with welded joints or where the water or piping is subject to considerable foreign matter.
8. A chilled water flow switch (or similar device) must be installed in the leaving water piping of the cooler. There should be a straight horizontal run of at least 5 pipe diameters on each side of the flow switch. Adjust the flow switch to suit the size of the pipe in which it is to be installed (see manufacturer's instructions furnished with switch). The switch is to be wired to terminals in the control panel as shown in the WIRING DIAGRAM.
9. The pump must be carefully selected to ensure it provides the design water flow against the total resistance of the system: Process heat exchanger, chiller vessel, static head, and all piping, valves and fittings.
10. The working water pressure at the chiller must not exceed 500kPa.

## **Electrical Connections**

A competent licensed electrician must carry out the electrical installation in accordance with local supply authority regulations and the appropriate unit-wiring diagram.

Any modifications carried out without the approval of Fluid Chillers Australia may void the unit warranty.

Mains supply cables must be sized to ensure adequate voltage at the unit terminals when the unit is starting and during full load operation.

Selection of supply cables must be determined by the following criteria:

1. Length of supply cable run.
2. Maximum starting current of unit - cables must supply adequate voltage at unit terminals for starting.
3. Method of installation of supply cables.
4. Capability of cables to carry starting and full load current, are provided on the unit's circuit diagram.

Short circuit protection must be provided at switchboard using HRC fuses or circuit breakers.

Supply cables run within the unit to the isolator switch must be adequately protected against mechanical damage. (Ref: AS3000).

## **Refrigerant Charge**

The chiller is shipped pre-charged with the correct amount of Refrigerant in the system.

At unit start-up, the operating pressures and temperatures, should be checked by a properly qualified refrigeration mechanic to verify the unit is properly charged.

## **Operating Limits**

For reliable efficient, trouble-free operation, it is essential that the unit is correctly sized for the job and operates within its recommended water flow and temperature range.

Units must not be selected to operate outside the range of operating conditions as shown in the selection data.

## **Warranty**

Fluid Chillers Australia Pty Ltd warrants its fluid chilling units to be free of defects in workmanship or material under normal use and service.

As Fluid Chillers Australia Pty Ltd has no direct control over field-work done during installation, claims resulting from damage to equipment which can be attributed to this field work cannot be accepted.

## **Water System**

Before attempting to start the unit, the chilled water system must be prepared for operation.

## **Flushing**

The chilled water system must be thoroughly cleaned by flushing to remove all foreign material and dirt. Use care not to flush any foreign material into or through the chiller vessel. The chiller vessel should be ready for immediate start on a clean system as the vessel is hot dip galvanised construction with copper tubes, if necessary flush separately from main pipework system.

## **Fill System**

Fill system with clean water run pump to circulate water and check for leaks. Check pumps runs continuously.

## **Air Removal**

All air must be removed from system before starting unit. On "open" systems air is generally removed by simply running the pump. On "closed" systems it may be necessary to fit air bleed points.

Stop pump and check system for air pockets, vent as necessary.

Confirm flow switch functions / is operational.

Check water condition – if evidence of corrosion in system arrange for water sample test.

## 5. Commissioning

### Water Treatment

To prevent corrosion and the build-up of scale and to keep the water free of algae and slime it is essential that a suitable corrosion inhibitor be added to the chilled water system.

The required quantity should be added to the system after it has been filled and checked for leaks.

### Anti-Freeze Additive (if required)

If system is to run below +4°C, anti-freeze such as Glycol or Ethanol (CSR Alcool-LF or similar) must be added to water in correct proportion. Check anti-freeze concentration in all systems.

#### NOTE:

**Pure Glycol or Ethanol are not corrosion inhibitor, some suppliers add inhibitor at point of manufacture otherwise inhibitor must be added separately.**

### Establish Water Flow Rate

For efficient and reliable operation of the chiller it is critical that the design water flow rate is established and confirmed before starting the chiller.

Once established the flow rate must not vary more than 10% during operation and must never fall below the minimum flow rate listed for the model.

Non-compliance of above will cause chargeable service calls, erratic unit operation and may also cause damage to unit and void warranty.

## 6. Pre-start Check List

### Start Up

Clean all surfaces and remove all litter.

Clean down external panels. Remove panels.

Check and tighten all electrical connections.

Check drain points and piping are clear.

Check water pump direction for correct operation.

Prove and check all water flows.

### Electrical Check

Electrical installation has been carried out according to unit wiring diagram and Supply Authority Regulations.

Correct size fuses or circuit breaker installed at switchboard.

Supply voltages as specified on unit circuit diagram.

Check that the actual supply voltage is within the required limits.

With the main isolating switch in the off position, make sure all line-started contacts meet with even pressure and the all moving parts move freely.

Check that the thermostats are set below the chilled water temperature and that the system on/off switches are in the off position.

### Visual Check

Clearance around unit including condenser air entry and discharge and service access.

Unit mounted as specified.

For loose or missing bolts or screws.

For refrigerant leaks in connections and components.

Spin outdoor fans by hand and check clearance.

### Compressors and Refrigeration

#### System

Compressors sump heating must have been operating for at least three hours before attempting to start



compressor.

Check to make sure that all refrigerant shut-off valves are open.

Running check: Start the compressor check for any unusual noise, vibration & on CA40 and CA80 check rotation direction of scroll compressors. Check condenser fans and pumps are operating in correct direction.

If the return water temperature at start-up is too high the compressor(s) may overload causing the chiller to shut down.

To prevent this occurring, temporarily reduce the water flow by closing the balancing valve until the return water drops below 20°C.

Check that condenser fans are running in correct direction (clockwise when looking from top). The reciprocating compressors are bi-directional.

### **OPERATING PRESSURES**

Operate the unit for a minimum of 20 minutes to ensure that the refrigerant pressures have stabilised, and check that they are within normal operating limits.

### **OPERATING TEMPERATURE**

Check and record discharge, suction and liquid temperatures.

Discharge pressure on cooling cycle should normally not exceed 2500kPa.

Suction superheat should be 7°K to 12°K.

Liquid should be sub-cooled to = 8°KTD.

Check compressor rotolock and service valve caps to ensure they are tight.

**In applications where the design leaving water temperature is below +5°C, the LRT LWT and LP safety controls must be reset for low temperature operation.**

**Each application will require its own specific settings.**

**The Thermostatic Expansion Valves may require re-adjusting at low temperatures for maximum performance from the equipment.**

**If required, after resetting these safety controls, all systems should be rechecked for correct function.**

### **FINAL SYSTEM CHECK**

Schraeder valve caps in place and secure.

Carefully and thoroughly leak test all connections in the refrigeration system, particularly the compressor rotolock and the service valve caps.

All panels and fan guards in place and secure.

Unit clean and left over installation material removed from area.

Adjust control thermostat to the temperature required.

Replace and secure all panels.

### **OPERATOR INSTRUCTIONS**

Instruct the operator on proper operation and care of the system.

#### **CAUTION:**

The unit isolating switch must be left on at all times in order to maintain operation of the compressor crankcase heaters.

The control box system switch(s) can be turned to the off position at such times, or a remote control switch can be installed.

### **FINAL ELECTRICAL CHECK**

#### **Operating voltage:**

Re-check voltage at unit supply terminals.

Check the compressor and condenser fan motor(s) amperages to make sure they are normal.

The correct amperage is included in the Electrical Data.

**NOTE: The outdoor fan motors are fitted with internal automatic reset overload devices**

#### **Controls:**

Check unit is wired for correct control of cooling function.

Check all operating and safety controls to ensure they are correctly adjusted (refer to Controls page)

## 7. Regular and Seasonal Maintenance.

These units have been designed for minimum maintenance. However, there are operational maintenance requirements that require regular attention to ensure optimum performance.

Maintenance of these units must be performed by appropriately trained and experience personnel.

**WARNING: Isolate unit from power supply before working on unit**

### OUTDOOR COIL

The coil surface will become laden with dust and may be blocked by leaves or papers over a period of time.

The surface should be inspected periodically and cleaned down gently by hosing as required. Extremely dirty coils may require chemical cleaning.

### ELECTRICAL

The contact surfaces of relays and contactors should be inspected regularly by a refrigeration mechanic or electrician and replace as judged necessary.

On these occasions the control box should be cleaned to remove any accumulation of dust or other contaminants.

All thermostats and pressure controls should be checked for correct operation and settings.

Fan and compressor current draw should be checked and compared to normal ratings.

- Check fuse rating and condition.
- Check for loose terminal screws.
- Visually check condition of contracts.
- Generally check for loose wiring

### REFRIGERATION

The refrigeration is hermetically sealed and should require no regular maintenance.

However, it is recommended that the system is leak tested and the general operating and control systems be checked on a regular basis.

The operating pressures should be checked particularly at these times, as they are an excellent guide to other areas of the system in need of maintenance.

All pressure controls should be checked to ensure correct settings are being maintained.

- Check for pipes or capillaries rubbing or vibrating.
- Check compressor for unusual noise or vibration.
- Check discharge temperature.
- Confirm crankcase heater is energised during off cycle.

### CHILLED WATER SYSTEM

Check pump is giving correct water flow rate and supply head pressure, also that it is operating smoothly and quietly.

Check that there are no leaks to system particularly pump gland-shaft seal.

Check pump motor for signs of overheating.

Remove and clean strainers where fitted.

Chiller vessel should require no maintenance other than draining of vessel and checking for sludge if operating in a dirty environment.

### SEASONAL SHUTDOWN

If it is intended to shut the chiller down for a period of time the following service procedures should be

completed.

## **SHUTDOWN**

Where freezing temperatures may be encountered chiller water piping should be disconnected from the supply and drained of all water.

Remove drain plug from chiller vessels(s).

Remove the pump-drain plug and leave it removed, so that any water which may accumulate, is drained.

Take measures to prevent the shut-off valve in the water supply line from being accidentally turned on.

Open unit-isolating switch and remove fuses only if chillers are drained.

Check for corrosion and clean and paint rusted surfaces.

## **RESTART AFTER SHUT DOWN**

With unit switched off at main isolator, check:

- All terminals are tight.
- 
- Wiring clear of or protected from pipe work and sharp edges.
- Clean Electrical Enclosure. Sump Heater: Check heater is energised (when the compressor is stationary) for three hours before compressor start.
- Clean out accumulated dirt.
- 
- Replace all drain plugs removed at shut-down time the previous season.
- 
- Refill can check system as detailed under "start up".
- 
- Recommission unit as detailed under "Commissioning".

## 8. Troubleshooting.

CA Series chillers are fitted with a fault light that if ON, generally indicates an internal fault with the chiller. In some cases external faults can generate a secondary internal fault within the chiller. If the fault is OFF, the fault will normally be external.

| SYMPTOM AND PROBABLE CAUSE  | PROBABLE REMEDY   |
|---|---|
| <b>No Display on Thermostat control. Refrigeration is not running.</b>                            |   |
| Control circuit On-Off switch is OFF  | Check control switch is ON  |
| Chiller water flow switch is open   | Check chiller water pump operation (including direction), check switch.         |
| Pump contactor tripped on overload  | Investigate reason for trip & reset if OK                                       |
| Control circuit breaker tripped   | Reset control circuit breaker   |
| Power line open   | Reset circuit breaker   |
| Improperly wired controls   | Check and rewire  |
| Low supply voltage  | Check supply voltage - determine location of voltage drop and remedy deficiency |
| Condenser fans tripped on internal overload   | Wait for fan motor to cool down and auto-reset                                  |
| <b>Display on Thermostat control is on. Refrigeration not running</b>                             |   |
| Loose terminal connection   | Check connections   |
| Improperly wired controls   | Check and rewire  |
| Contactors stuck open   | Replace contactor   |
| Motor winding open or short circuited   | Check and replace compressor if faulty  |
| <b>Display on Thermostat control is on. Refrigeration not running. Fault light is on.</b>         |   |
| <b>Low Refrigerant Pressure Lock Out</b>  |   |
| Low or restricted chiller water flow  | Set water flow to designed requirements   |
| Brine solution has diluted  | Return brine solution concentration to correct level                            |
| Low refrigerant charge  | Add refrigerant, check for leaks and repair                                     |
| Compressor suction shutoff valve partially closed   | Open valve  |
| Safety device tripped   | Reset control circuit with On-Off switch. Determine cause of fault              |
| <b>High Refrigerant Pressure Lock Out - Note: HP lockout must be manually reset on HP control</b> |   |
| Condenser fans not operating  | Check motor winding and repair or replace if defective                          |
| Dirt or rubbish blocking condenser coil   | Clean coil  |
| Compressor discharge valve partially closed   | Open valve or replace if defective  |
| Air in system   | Purge system of air, find leak and repair                                       |
| Safety device tripped   | Reset control circuit with On-Off switch. Determine cause of fault              |
| <b>Unit Operates Too Long or Continuously</b>   |   |
| Control contacts fused  | Replace control   |
| Cooling load exceeds chiller capacity   | Reduce load on chiller  |
| Non-condensable in system   | Purge system of air, find leak and repair                                       |
| Partially plugged expansion valve or filter drier   | Clean or replace  |
| Low refrigerant charge  | Add refrigerant and determine reason for loss                                   |

| System Noisy                                    |  |
|---|--|
| Fan out of balance                              | Re-balance or replace fan blade or complete assembly           |
| Crankcase heaters not energised during shutdown | Check wiring and relays. Check heater and replace if defective |
| Compressor noise                                | Replace compressor if determined faulty                        |

### COMISSIONING DATA SHEET

|   |   |
|---|---|
| Purchased from: <input style="width: 150px; height: 20px;" type="text"/>  | Date: <input style="width: 100px; height: 20px;" type="text"/>          |
| Model number: <input style="width: 150px; height: 20px;" type="text"/>    | Serial number: <input style="width: 100px; height: 20px;" type="text"/> |
| Invoice number: <input style="width: 150px; height: 20px;" type="text"/>  | Invoice date: <input style="width: 100px; height: 20px;" type="text"/>  |
| Equipment owner: <input style="width: 400px; height: 20px;" type="text"/> |   |

#### CHILLED WATER/GLYCOL SYSTEM

|                                     |       |   |   |
|-------------------------------------|-------|---|---|
| Anti-freeze type if used            |       |   |   |
| % solution by volume of anti-freeze | % vol |   |   |
| Water/Glycol pressure entering unit | kPa   |   |   |
| Water/Glycol pressure leaving unit  | kPa   |   |   |
| Water/Glycol - flow measured        | L/s   |   |   |
| Full/Part load temperature entering | C     |   |   |
| Full/Part load temperature leaving  | C     |   |   |
| Ambient temperature                 | C     |   |   |
| Air leaving condenser temperature   | C     |   |   |
| Line voltage                        | V     | V | V |
| Control voltage                     | V     |   |   |
| Compressor full load Amps           | A     | A | A |
| Chiller full load Amps              | A     | A | A |

#### REFRIGERATION SYSTEM

|  | System 1 |     | System 2 |     | System 3 |     |
|--|----------|-----|----------|-----|----------|-----|
| Discharge pressure                           |          | kPa |          | kPa |          | kPa |
| Discharge temperature                        |          | C   |          | C   |          | C   |
| Suction pressure                             |          | kPa |          | kPa |          | kPa |
| TX bulb temperature                          |          | C   |          | C   |          | C   |
| Liquid line temperature                      |          | C   |          | C   |          | C   |
| Liquid entering evaporator temperature       |          | C   |          | C   |          | C   |
| Suction line temperature entering compressor |          | C   |          | C   |          | C   |

To ensure prompt warranty consideration please fill out this page, photocopy, fax or e-mail to Fluid Chillers Australia Pty Ltd.









